

1. code number: up to 10
2. * is the cancel key.
3. # is opening key
4. Temporary code: S1=off, Perminant code: S1=On
5. Perminanet code setting: S1=on, and S2=on: Enter new code, click #,. After the setting, move S2 to Off
6. Temporary code: S1=Off, and S2= Off. Enter new code, click #
7. If three times error, red light for 60 second. If less then 3 times, red light flash for .5 second
8. If the power less than 4.8V, open lock, then red light flash 8 second
9. Set iButton set up card: push reset button, hold it, touch the ibutton, you will hear double beep
10. Set management card: software program card. First touch, open lock, second immediate touch, close lock. Third touch, add card. Touch key again, delete card. Touch key 5 times,, clear all the keys